


## Models MXL - 4.5 Parts List □



1 - Main Housing□	MXL4.5-001			
2 - Gear cover□ □	MXL4.5-002			
3 - Cover Screw (2 req.)□	MXL4.5-003			
4 - Spool Shaft□□	MXL4.5-004			
5 - Belleville Washers (4 req.)□	MXL4.5-005			
6 - Pusher Bushing□	MXL4.5-006			
7 - Spool Bearing □	MXL4.5-007			
8 - Spool Tube□□	MXL4.5-008			
9 - Clicker Gear Retainer Ring	MXL4.5-009			
10- Clicker Gear Ⅲ	MXL4.5-010			
11- Spool □ □	MXL4.5-011			
12- Brake Pad □ □	MXL4.5-012			
13- Brake Pad Retainer Ring□	MXL4.5-013			
14- Spool Bearing □	MXL4.5-014			
15 - Spool Spring Washer (2 req.) MXL4.5-015				

16 - Spool Spring□	MXL4.5-016
17 - Brake Bearing □	MXL4.5-017
18 - Brake Disk□□	MXL4.5-018
19 - Pinion Gear	MXL4.5-019
20 - Pinion Bearing □	MXL4.5-020
21 - Gear Screw ■	MXL4.5-021
22 - Drive Gear □ □	MXL4.5-022
23 - Drive Shaft□□	MXL4.5-023
24 - Drive Shaft Bearing (2 req.)□	MXL4.5-024
25 - End Housing □	MXL4.5-025
26 - Untireverse Dog (2 req.)□	MXL4.5-026
27 - Dog Spring (2 req.)□	MXL4.5-027
28 - Dog Cover Screw (4 req.)	MXL4.5-028
29 - Dog Cover (2 req.)□	MXL4.5-029
30 - Stop Pin (2 req.)□	MXL4.5-030
• • • • • • • • • • • • • • • • • • • •	

31 - Stop Pin Screw□	MXL4.5-031	
32 - End Housing Screw (3 req.)□	MXL4.5-032	
33 - Male Cam□ □	MXL4.5-033	
34 - Female Cam □	MXL4.5-034	
35 - Lever Arm $\square$	MXL4.5-035	
36 - Handle Knob□	MXL4.5-036	
37 - Knob Screw □	MXL4.5-037	
38 - Cam Insert□□	MXL4.5-038	
39 - Insert Washer□	MXL4.5-039	
40 - Priset Spring ☐	MXL4.5-040	
41 - Preset Knob 🗆	MXL4.5-041	
42 - Drive Shaft Tube□	MXL4.5-042	
43 - Drive Shaft Washer□	MXL4.5-043	
44 - Crank Arm □ □	MXL4.5-044	
45 - Crank Arm Washer□	MXL4.5-045	

46 - Akorn Nut□ □	MXL4.5-046
47 - Locking Plate □	MXL4.5-047
48 - Plate Screw (2 req.)□	MXL4.5-048
49 - Handle Stem Washer□	MXL4.5-049
50 - Handle Tube washer□	MXL4.5-050
51 - Handle Tube□	MXL4.5-051
52 - Lock Screw Nut□	MXL4.5-052
53 - Handle Shoulder Bolt□	MXL4.5-053
54 - Lock Screw Washer□	MXL4.5-054
55 - Lock Screw□	MXL4.5-055
56 - Handle Knob□	MXL4.5-056
57 - Clicker Pin □ □	MXL4.5-057
58 - Pin Support□	MXL4.5-058
59 - Rod Mount□□	MXL4.5-059
60 - Rod Mount Screw (2 req.)□	MXL4.5-060

10	
61 - Rod Mount Clamp□	MXL4.5-061
62 - Clamp Screw□	MXL4.5-062
63 - Pin Washer□	MXL4.5-063
64 - Clicker Spring (2 req.)□	MXL4.5-064
65 - Clicker Arm□	MXL4.5-065
66 - Pin E-Clip□ □	MXL4.5-066